SnowFire

Bluetooth Speaker

CUBE-BTS-05

USER MANUAL



Thank you for choosing SnowFire.

Safety Instructions

Read this manual carefully before putting the applicance into operation and keep this manual for future reference.

- **Do not use the device with wet hands.**
- **To mininize the risk of fire or electrical shock, avoid operating in wet conditions such as rain or humidity. Do not operate around water (e.g. bathroom, swimming pool, etc.)**
- **Keep the device away from heat, direct sunlight and sharp edges.**
- **Do not insert any metal object into the device.**
- **To avoid a static charge, do not use the device in an extremely dry climate.**
- **Do not attempt to repair the device yourself.**

Product overview



Accessories included

1. **Line-in cable**
2. **USB charging cable**

Integrated Rechargeable Battery

The SnowFire Bluetooth speaker is powered by an integrated rechargeable lithium battery.

Charging battery

1. **Insert the micro USB plug into the DC 5v socket on the unit. Connect the USB plug to a USB port on a PC or an AC/DC adapter. The LED indicator turns red to indicated the battery is charging.**
2. **When the battery is fully charged, the red LED indicator will go out.**

Pairing SnowFire CUBE-BTS-05 to Bluetooth device

1. **Turn off the speaker. Make sure the speaker is in power off mode.**
2. **Press and hold the on/off button for about 6 seconds until the LED is flashing red and blue alternatively.**
3. **Turn on your Bluetooth enabled device and activate the Bluetooth function.**
4. **Search for the Bluetooth device, « BTS-05 » will show up.**
5. **Pair your mobile phone with « BTS-05. » If a password is needed, type in '0000'. After the SnowFire BTS-05 is paired with your device, connect it to your device**

Tips :
Once the speaker is paired and connected to your Bluetooth device, it automaticaly connect the next time as long as the Bluetooth on your device is turned on.

Button Functions

On/off : To switch on or off the unit.
Down : Quickly press for the previous song. Press and hold to turn down the volume.
UP ; Quickly press for the next song. Press and hold to turn up the volume.
Phone : Press to pick up an incoming call or to hang up the phone.

The phone button also will play or pause music.

Tips :
You can press the Phone button twice quickly to redial the last phone number.

Troubleshooting

Symptoms	Causes	Solutions
Can not switch the speaker on	Battery needs charging	Charge the battery
Unable to pair the speaker	Speaker is not in pairing mode.	Refer to the section on pairing.

Technical Specifications

Bluetooth version : 3.0+EDR
Range : 10 meters
Transmitting frequency : 2.4GHz
Power supply : DC 5V
Battery : 3.7v/400mAh lithium
Charging time : approx. 3 hours
Operating time : approx. 6 hours
Unit weight : approx. 0.229KGS